

Returning trigger weight to factory settings

Warning

Adjusting the trigger weight too low may cause an unintentional discharge.

1. Loosen the 5/16" jam nut on the trigger-weight screw. Turn the trigger-weight screw counter clockwise approximately four turns using a 1/16" allen wrench.
2. Pull the trigger and depress the sear. (*Figure 33, Step A and B.*) Turn the trigger-weight screw clockwise until the plunger is fully compressed in the trigger-weight screw. Turn the trigger-weight screw counter clockwise 1/4 turn and tighten the brass jam nut.

